

# WARNING!

CLEAN THE ENTIRE SURFACE THOROUGHLY PRIOR TO INSTALLATION WITH A MIXTURE OF ONE HALF ISOPROPYL ALCOHOL AND ONE HALF TAP WATER.

AFTER THIS PRODUCT HAS BEEN PROPERLY INSTALLED, THE STRUCTURAL BONDING TAPE REQUIRES 72 HOURS TO CURE AT ROOM TEMPERATURE. THE APPLICATION OF HEAT WITH A HAIR DRYER WILL GREATLY REDUCE THIS CURE TIME.

APPLY ENOUGH PRESSURE TO INSURE THAT THE PRODUCT HAS ACHIEVED GOOD CONTACT WITH THE SURFACE BELOW. EXTREME CARE MUST BE TAKEN TO AVOID OVERHEATING WHICH WILL CAUSE THE STAINLESS MATERIAL TO WARP.

## **TIMELY TIPS:**

1. IF YOU CAN'T HOLD YOUR HAND ON IT - IT'S TOO HOT.
2. MAKE SURE THE PLASTIC COATING (P.V.C.) IS REMOVED PRIOR TO PERFORMING THIS OPERATION.

12-23-96

**08300INS**