



## INSTRUCTIONS

### FOR ALL PETERBILT FUEL TANK TRIM CHANNELS

1. Mount all lights and connecting harness prior to installation.
2. Jack up fuel tank to remove pressure from tank straps.
3. Loosen tank strap mount bolts far enough to permit installation of the trim channel mounting clips.
4. Slide mounting clips BETWEEN rubber and tank straps as shown in illustration.
5. Bolt trim channel in proper position and tighten.
6. Re-tighten tank straps.
7. Connect wiring leads to the truck.