




379 PETERBILT FENDER SHIELDS

(WITH ROUND HEADLAMPS
AND STANDARD "PETE" STEPS)




HOLE LOCATION ILLUSTRATION

REAR ILLUSTRATION

COPYRIGHT © 2007
RigSkirts LLC.
ALL RIGHTS RESERVED

INSTRUCTIONS

1. UNPACK THE CARTON AND DETERMINE THAT YOU HAVE RECEIVED ALL OF THE PARTS NECESSARY TO COMPLETE THIS INSTALLATION.
2. INSTALL BOTH MOUNTING ANGLES ONTO THE BACK OF EACH FENDER SHIELD AS SHOWN IN THE "REAR ILLUSTRATION" LEAVE ALL OF THE BOLTS IN A "FINGERTIGHT" CONDITION UNTIL THIS INSTALLATION HAS BEEN COMPLETED.
3. LOCATE AND DRILL THE TWO 3/8" HOLES AS SHOWN IN THE "HOLE LOCATION ILLUSTRATION" (ONE HOLE IN EACH STEP - 7/8" FROM THE FRONT OF THE STEP). **NOTE!** IT IS BEST TO MARK THE HOLE CENTERS WITH A CENTER PUNCH TO PREVENT THE DRILL BIT FROM "WALKING".
4. PLACE THE ASSEMBLY ON TOP OF THE STEP. INSERT ONE LONG CARRIAGE BOLT THROUGH THE SMALL PLATE WITH A SQUARE HOLE. INSTALL THIS UNIT UP FROM THE BOTTOM (HOLLOW PART) OF THE STEP AND ON THROUGH THE DRILLED HOLE AND ANGLE BRACE. PLACE A NUT, WASHER AND LOCKWASHER ON THE BOLT. (SEE "SIDE ILLUSTRATION")
5. INSERT ONE LONG CARRIAGE BOLT THROUGH THE LARGE PLATE WITH A SQUARE HOLE. INSTALL THIS UNIT FROM UNDER THE **OPEN** PART OF STEP AND THROUGH THE ANGLE BRACE. PLACE A NUT, WASHER AND LOCKWASHER ON THE BOLT.
6. PROPERLY ALIGN THE FENDER SHIELDS AND TIGHTEN ALL BOLTS. **NOTE!** IT IS A GOOD IDEA TO APPLY A SMALL AMOUNT OF "LOCTITE" TO THESE BOLTS TO PREVENT THEM FROM VIBRATING LOOSE DURING NORMAL OPERATIONS.
7. USE WINDEX AND A SOFT COTTON CLOTH TO CLEAN THE FENDER SHIELDS AFTER THE INSTALLATION IS COMPLETED. NEVER USE AN ABRASIVE COMPOUND TO CLEAN THE STAINLESS AS IT WILL DAMAGE THE FINISH.
8. IT IS A GOOD IDEA TO CHECK THE FENDER SHIELD BOLTS PERIODICALLY TO INSURE THAT THEY HAVE REMAINED TIGHT DURING NORMAL OPERATION OF THE TRUCK.



SIDE ILLUSTRATION



BY

