




REAR DECK PLATES



INSTRUCTIONS

1. LEAVE THE P.V.C. PROTECTIVE COATING ON THE REAR DECK PLATE AND PLACE INTO THE APPROXIMATE FINAL POSITION. MARK THE LOCATION OF BOTH ENDS. THERE SHOULD BE PLENTY OF ROOM FOR FINAL ADJUSTMENT IF YOU ARE CAREFUL TO PLACE THE MOUNTS TO MISS ANY OBSTRUCTIONS.
2. REMOVE THE DECK PLATE FROM THE TRUCK.
3. LOOSEN THE BOLTS ON ALL OF THE BRACES AND PLACE THEM INTO THEIR APPROXIMATE FINAL POSITION AND TIGHTEN TO A "FINGERTIGHT" CONDITION.
NOTE! IT IS BEST TO KEEP THE TWO END BRACES APPROXIMATELY 3" TO 6" FROM EACH END OF THE DECK PLATE.
4. MEASURE FROM THE MARKS YOU PLACED AT BOTH ENDS OF THE DECK PLATE TO THE CENTER OF THE SLOTS IN THE TOP OF THE ANGLE. THIS LOCATES THE HOLES FROM EACH OF THE ENDS. YOU MUST NOW LOCATE THE HOLES FROM SIDE TO SIDE.
5. PULL BOTH PIECES OF EACH BRACE TIGHTLY TOGETHER AND TIGHTEN THE BOLTS. (IT IS NOT NECESSARY TO WORK FROM UNDER THE TRUCK)
6. DRILL THE 5/16" (.312 DIA.) HOLES IN THE DECK PLATE. IT IS BEST TO USE A CENTER PUNCH TO PREVENT THE DRILL BIT FROM "DRIFTING".
7. LAY THE DECK PLATE BACK INTO THE PROPER POSITION AND MAKE SURE THE HOLES LINE UP WITH THE SLOTS IN THE TOP OF THE BRACES.
8. PEEL THE P.V.C. COATING FROM THE DECK PLATE AND BOLT IT TO THE BRACES.
9. CHECK FOR PROPER ALIGNMENT AND TIGHTEN ALL BOLTS.



BY

